












ČASTI x KS Návod na montáž: FARAN D-109

Ax1 	Hx5 
Bx1 	Ix10  M6x10mm
Cx2 	Jx4  M6x20mm
Dx1 	Kx2  M6x25mm
Ex1 	Lx4  M6x30mm
Gx1 	Mx1 