

















- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod






A	B	C (mm)		D
1	S215-020	432	204	2/2
2	S215-124	303	399	1/2
3	S215-125	303	399	1/2
4	S215-322	438	397	1/2
5	S215-323	438	358	1/2
6	S215-413	438	60	1/2
7	S215-902	227	448	1/2
8	WSP-910	408	308	1/2
9	WSQ3-503	300	120	1/2
10	WSQ3-504	300	120	1/2
11	WTQ-5015	398	107	1/2










2








3




4





5



6



7



Pflegehinweis!

Bitte nur mit einem Staubtuch
(kein Microfasertuch) oder
einem feuchten Lappen reinigen.
KEINE scheuernden Putzmittel
verwenden!

Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko
wilgotną szmatką do kurzu. Nie używać
żadnych środków szorstkich!

