




(D) Montageanleitung
(FR) Notice de montage
(NL) Handleiding voor de
(CZ) Montážní návod
(HU) Szerelési útmutató
(TR) Montaj talimatı





3 - 3,5







GB Assembly instructions
IT Istruzioni di montaggio
PL Instrukcja montażu
SK Návod na montáž
RO Instrucțiuni de montaj
RU ИНСТРУКЦИЯ ПО МОНТАЖУ




B	 x22	A	 x72 8x35	ZF	 x8	P	 x8	OE	 x6	H	 x22 6,3x13	S	 x1 L=305	L=470	 x2	SC		X	 x120	ZB	 x8 H=0	R	 x11 7x50	N	 x24 3,5x16	Y	 x64 10mm	T	 x4	SB	 x1	G	 x6 L=500	C	 x22 15x12	ZK	 x22 20mm	PA	 x3	NW	 x12 4x30	Y	 x64 3,5x16	SC	 x2 L=470	L=305	 x1	ZB	 x8 H=0
----------	---	----------	---	-----------	--	----------	---	-----------	---	----------	--	----------	--	--------------	---	-----------	---	----------	---	-----------	--	----------	--	----------	--	----------	--	----------	--	-----------	---	----------	--	----------	---	-----------	--	-----------	---	-----------	--	----------	--	-----------	--	--------------	---	-----------	--




2




7



9



10



8

